





How to Start RTK with Base R8 and Rover R10 connected via BT and Internal Radio

Select Survey Styles




Select RTK and hit edit if it exists, or create new Style








Select Rover options




In Rover options make sure Survey type is RTK, Broadcast format is CMRx and click accept. If you are using an older model (R8 – Model 2) you should select CMR+ for Base and Rover!








Select Rover radio



In Rover radio make sure Type is Receiver internal and Method is Trimble 450/900 and click on Connect








Connecting to radio




Radio configuration make sure radio operation mode is Rover, Frequency 464.50000 MHz and Base radio mode is TT450s at 8000 bps and hit Enter (Frequencies must match Base as well!)








Select Base options




In Base options make sure your Survey type is RTK and your Broadcast format is set to CMRx








In Base options make sure to select R8 GNSS antenna if it was model 3 or whatever is your receiver




In Base options make sure to your screen look exactly like the below image and accept








Select Base radio




In Base radio select Receiver internal for Type and Method Trimble 450/900








Connecting to Base receiver



Connecting to Base receiver, hit connect











Make Sure to match your frequencies with your rover








Make sure the base radio mode matching your rover




Hit Accept








Make sure to store your edits




You are done with the survey style, hit ESC







You are done with the survey style, hit X



Click on General Survey








Start a new job or existing one




Select RTK Survey Style








Start your Base








Select a point to start from




Select a point from a List or Key In








Or Start from here position (autonomous), Click here and it will populate your fields











Enter Antenna height








Select Measured to and hit Start to start your Base







The Base started




Go to Measure








Select your Survey Style RTK




Select Measure points








Connecting to Rover











Select Accept







You will start receiving corrections from the base and start Initializing



You Can start Measurement now

