



How to load the Geoid model in the TSC7:

- 1) Load the Geoid to a thumb drive
- 2) Insert the thumb drive into the Tsc7
- 3) On the main desktop select the windows icon and scroll to the bottom of the listing and select "This PC"
- 4) Go to USB drive (likely D drive)
- 5) Press and hold on the Geiod model and select copy
- 6) Open Trimble Access
- 7) Open a job (if there are no previous jobs, create a new job)
- 8) Select the menu tab in the top right corner represented by three horizontal lines in the top left corner
- 9) Select job data
- 10) Select File Explorer
- 11) In the file path shown select Trimble Data
- 12) You should then see System files
- 13) Select the System file folder, press and hold, and select paste
- 14) You can now close these windows
- 15) Go into your project, select the job then properties at the bottom and choose it under your coordinate system menu