# How to connect R8 and R10 via BT

Turn on your TSC3 Data collector and click on Start

Start Trimble Access

Trimble Access 2014.10 started (or Any Version)


Click on Settings

Click on Connect

Click on Bluetooth

Click on Configuration

Click on Add new devices

Searching for Bluetooth Devices



Select a device to connect

Select R10 and click next

Leave Passcode blank and hit next

R10 added successfully


Click on Add new device

Searching for Bluetooth Devices


Select R8 and click next

Leave Passcode blank and hit next

R8 added successfully

R10 & R8 and the devices list, click OK

Select your Rover and Base from the drop down list

Select your Rover to be R10

Select your Base

Select your Base from the drop down list and make sure it is not R10

Select your Base to be R8 and Accept